



### Fitting Instructions:

- 1) Trim out a suitable opening and fix noggins spanning between trusses to form a clear opening of 562mm x 562mm.
- 2) Fit a layer of 12.5mm plasterboard 95mm up the edge of the joist. This leaves an opening of 537mm x 537mm.
- 3) The ceiling should preferably be fully finished and painted before installation of the unit. Offer up the door and frame in the open position ensuring it sits squarely and flush against the ceiling. Use 50mm long woodscrews to secure the frame through the 16 no. pre punched holes. Finally seal around the join between the frame and ceiling using a fire resistant mastic.
- 4) Close the door and lock the catch use the 'T' key provided.

MANTHORPE BUILDING PRODUCTS LTD  
 MANTHORPE HOUSE  
 BRITAIN DRIVE  
 CODNOR GATE BUSINESS PARK  
 RIPLEY  
 DERBYSHIRE DE5 3ND

TEL: 01773 303 000  
 FAX: 01773 303 300  
 EMAIL:  
 mbp.care@manthorpebp.co.uk  
 WEB  
 www.manthorpebp.co.uk

DRN M.R Date 31.07.19

The company maintains a policy of continuous development of its product range and reserves the right to amend the specification without notice.

DRG No

**MBP 8202**

Issue

**D**